Command Line

How do I enable autologin on TTY running on the Controllers serial port [Raspbian Buster/Bullseye/Bookworm]?

To enable auto logins on the TTY running on any serial port on the Controller log in and run the following commands changing "**USERNAME**" to your username and reboot.

```
sudo mkdir -p /etc/systemd/system/serial-getty@ttyS0.service.d/
sudo bash -c "cat > /etc/systemd/system/serial-
getty@ttyS0.service.d/autologin.conf << EOF
[Service]
ExecStart=
ExecStart=-/sbin/agetty --autologin USERNAME --noclear %I \$TERM
EOF"
```

And to disable it run the following command and reboot.

```
sudo rm -rf /etc/systemd/system/serial-getty@ttyS0.service.d/
```

When enabling this all users with access to the Controller Pi serial port will be able to log in without any authentication.

Unique solution ID: #1109
Author: n/a
Last update: 2024-01-02 11:30

© 2024 Chris Burton <Chris@Burton.email> | 2024-03-28
https://8086.support/content/13/110/en/how-do-i-enable-autologin-on-tty-running-on-the-controllers-serial-port-raspbian-buster_bullseye_bookworm