

Computers

How do I boot a Supermicro motherboard using PXE?

To boot with PXE you must first enable the network cards BIOS within your system BIOS and then when booting press F11 which will show the boot menu.

Unique solution ID: #1043

Author: n/a

Last update: 2014-12-16