

Command Line

How do I stop the HAT EEPROM being loaded on a Raspberry Pi?

To prevent the device tree configuration from being loaded from a Raspberry Pi HAT add the following to your config.txt file.

```
force_eeprom_read=0
```

Unique solution ID: #1112

Author: n/a

Last update: 2019-11-16