

# Gadgets

## How do I pair a Current Cost transmitter with an Envi/CC128 Monitor

Follow this procedure to pair the Transmitter (standard or mini) on an appliance channel.

1. Press the “Up” or “Down” buttons until you find the Appliance channel you wish to pair the transmitter on. The Appliance channel number is shown in the lower right hand corner of the display (where the main channel shows the current temperature).
2. Press the recessed button on the transmitter.
3. Press and hold the “OK” button on the monitor until the red light flashes (within 60 seconds of pressing the transmitter button).
4. The monitors display will now search for the device and then update the display to show the current usage.

Unique solution ID: #1004

Author: Chris Burton

Last update: 2014-12-16 21:29